



Providing sustainable energy solutions worldwide

Installation and Maintenance Manual

CTC EcoComfort

Passive cooling unit

Important!

- Read carefully before use, keep for future reference.
- Translation of the original instructions.



CTC EcoComfort

Passive cooling unit



Table of contents

Congratulation on buying your new product!	5	3.8	Connecting the diverting valve (Y60)	14
Safety instructions	6	3.9	Non-return valve, cooling circuit	15
Check list	7	3.10	Non-return valves, main circuit's brine system	15
The check list must be completed by the installer.	7	3.11	Bleeding the cooling unit	15
Pipe installation	7	3.12	Connection to the brine system	15
Electrical installation	7	3.13	Insulating the pipes	15
Customer information (adapted to the relevant installation)	7	3.14	Pressure drop curves for CTC EcoComfort	16
1. Installation	8	4. Electrical connection	17	
1.1 Scope of delivery	8	4.1	Alt. 1. Connection to CTC controlling product, common underfloor heating/cooling	18
1.2 Important to remember!	8	4.2	Alt. 2. Connection to CTC controlling product, underfloor/radiator heating and separate cooling coil units	18
1.3 Technical data	9	5. First start	19	
1.4 Dimensional drawing	9	5.1	After installation	19
2. Schematic diagrams	10	5.2	Start-up	19
2.1 Alt. 1. Connection to the CTC controlling product, common underfloor heating/cooling	10	5.3	Selecting cooling function	19
2.2 Alt. 2. Connection to the CTC controlling product, underfloor/radiator heating and separate cooling coil units	11	5.4	Selecting system type/Menu settings	19
2.3 Component location	12	5.5	Bleeding and function test	19
3. Pipe installation	13	6. Operation and maintenance	20	
3.1 General	13	6.1	After installation	20
3.2 Mounting	13	6.2	Periodic maintenance	20
3.3 Water quality, cold side	13	6.3	Breaks in operation	20
3.4 Water quality, hot side	13	6.4	Function description	20
3.5 Delivery inspection	13	6.5	Function options	21
3.6 General comment on pipe installation	13	7. Troubleshooting and remedial action	23	
3.7 Connection to the heating system	13	7.1	Capacity data	24

For your own reference

Fill in the information below. It may come in useful if anything should happen.

Product:	Manufacturing number:
Installer:	Name:
Date:	Tel. no.:
Electrical installer:	Name:
Date:	Tel. no.:

Enertech AB provides the information with reservation for any printing errors and subject to modification.

Congratulation on buying your new product!



You have just bought a CTC EcoComfort passive cooling unit, an accessory to the CTC controlling product.

CTC EcoComfort is an accessory that utilises the cold in the bore hole to cool your house during the summer. By connecting CTC EcoComfort to the house's underfloor heating system (or separate fan coil units), its water is cooled by the bedrock's cooler collector water. The heat in the house is taken out into the bore hole in the bedrock.

The unit is completely pre-wired at the factory and easy to connect to the system.

The cooling function is controlled entirely from your controlling product on which you can set your preferences for when and how you would like cooling.

This type of cooling is energy efficient – only circulation pumps circulate the cool water. The capacity is, however, slightly lower compared to so-called active cooling where the more energy-intensive compressor works to create coldness.

The system can be connected to underfloor heating or separate fan coil units.

Connection to an underfloor heating system (underfloor cooling) limits the temperature of the water circulating in the heating system. A temperature that is too cold can lead to condensation forming and result in serious damage. The current room temperature should also be considered.

Connection to separate fan coil units where the system is insulated against condensation and condensation collects in the fan coil unit can permit very low temperatures.

The unit's cooling capacity is dependent on several factors such as the flows and the temperature of the bore hole and house. The unit's capacity is at its greatest in the first part of summer, when the bore hole is still cold after the winter's heat extraction.

Safety instructions



Turn off the power with an omnipolar switch before doing any work on the product.



The product must be connected to protective earth.



The product is classified as IP X1. The product must not be rinsed with water.



Never jeopardise safety by removing bolted covers, hoods or similar.



The product's electrical systems should only be installed and serviced by a qualified electrician.

-If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



This device can be used by children from the age of eight years and above and by people with reduced physical, sensory or mental ability or lack of experience or knowledge if they have been taught, either with supervision or with the instructions provided, how to use the device safely and understand the risks involved. Children should not play with the device. Cleaning and maintenance should not be carried out by children without supervision.



If these instructions are not followed when installing, operating and maintaining the system, Enertech's commitment under the applicable warranty terms is not binding.

Check list

The check list must be completed by the installer.

- In the event of a service, this information may be called for.
- Installation shall always be done according to the Installation and maintenance manual.
- Installation shall always be carried out in a professional manner.
- Following installation, the unit shall be inspected and checked for functionality.

The points below shall be checked off.

Pipe installation

- The system has been filled, positioned and adjusted in the correct manner according to the instructions.
- The products are positioned so that they can be serviced.
- Pumps, valves, etc. are dimensioned for the required flows.
- The unit has been tested for leaks and tightness.
- Bleeding performed (re-bleeding may be necessary).

Electrical installation

- Proper wiring, performed according to current regulations.
- Correct connection to the controlling product.

Customer information (adapted to the relevant installation)

- Start-up with customer/installer.
- Review of the cooling unit's function.
- Installation and maintenance manual supplied to the customer.
- Check and filling, system.
- Information on fine adjustments, settings, etc.
- Information on potential operational malfunction and remedial action.
- Guarantees and insurance.
- Information and procedure for fault registration.

1. Installation

1.1 Scope of delivery

The following items are included in the delivery of a CTC EcoComfort passive cooling unit:

- Packaging box with impact protection
- Cooling unit fitted in enclosed box containing:
 - Heat exchanger
 - Circulation pump (circulates brine in the collectors)
 - Mixing valve with mounted steering motor, including 2 m connection cable
 - Non-return valve
 - Bleeding valve for the cold side (brine)
 - Support sleeves in copper pipe connections
- Non-return valve for main brine system
- Installation and Maintenance Manual

1.2 Important to remember!


Check the following points in particular at the time of delivery and installation:

- Check before installation that the product has not been damaged in transit. Report any transportation damage to the carrier.
- Make sure the heating system is suitable for cooling, and the type of system (underfloor heating, fan coil units).
- Make sure the product is mounted horizontally.
- Make sure the wall is suitable for installation, and no hidden electrical cables/pipes can be damaged during installation.
- Remember to leave a service area around the product.
- The radiator system's water flow passes through the heat exchanger in CTC EcoComfort. This is why the radiator system must be flushed thoroughly before installation.
- The packaging must be deposited at a recycling station or with the installation engineer for correct waste management.
- Obsolete products must be disposed of correctly and transported to a waste station or distributor/retailer offering this service. Disposal of the product as household waste is not permitted.

1.3 Technical data

CTC EcoComfort passive cooling unit			
Electrical data (components powered by the CTC controlling product)	230 V 1N~ 50 Hz	Approx. 2 x 2.5 m cable from cooling unit included for connection to the controlling product	
IP class	IP X1		
Nominal power output	kW	0.03	
Volume (V) cold/hot side	l	0.46/0.54	
Max. operating pressure (PS)	kPa/Bar	1/10	
Min./max. operating temperature (TS)	°C	+2/80	
Weight excl. packaging (net)	kg	11	
Weight incl. packaging	kg	12.5	
Dimensions incl. packaging (DxWxH)	mm	310x280x580	
Basic dimensions excl. packaging (DxWxH)	mm	220x255x410	
Height incl. connections	mm	470	
Pipe connections (4 pcs)	mm	Ø22	Copper
Capacity	See separate section		
Non-return/throttle valve, main brine system	Rp	1"	Internal thread


1.4 Dimensional drawing



2. Schematic diagrams


2.1 Alt. 1. Connection to the CTC controlling product, common underfloor heating/cooling

The diagram shows schematically how CTC EcoComfort is connected to the systems; additional equipment, such as expansion vessels, shut-off valves, safety valves, buffer tank etc., is not shown here. The controlling product in this example is the ground source heat pump CTC GSi. In this example (Alt. 1), the diverting valve Y60 is connected to the combined heating/cooling circuit as well as to the controlling product and CTC EcoComfort. The diverting valve is controlled by the controlling product.




2.2 Alt. 2. Connection to the CTC controlling product, underfloor/radiator heating and separate cooling coil units

The diagram shows schematically how CTC EcoComfort is connected to the systems; additional equipment, such as expansion vessels, shut-off valves, safety valves, buffer tank etc., is not shown here. The controlling product in this example is the ground source heat pump CTC GSi.



2.3 Component location

- A. Connection water flow in.
 - B. Connection water flow out (cooled water).
 - C. Incoming connection from bedrock collector
 - D. Outgoing connection to bedrock collector
1. Box with lid, tight design
 2. Cold side, brine system
 3. Hot side, heating system
 4. Heat exchanger
 5. Mixing valve with motor for cooling control
 6. Circulation pump, bore hole circulation
 7. Bleeder, cold side (brine)
 8. Non-return valve, cooling unit (in the pipe)
 9. Cables for connection to the controlling product (2.5 m)
 10. Non-return/throttle valve, main system (brine), provided
 11. Block for manual control




3. Pipe installation

3.1 General

This chapter is intended for anyone responsible for the installation. Take your time going through functions and settings with the property owner and answer any questions. Installation must be performed by a qualified professional.

3.2 Mounting

CTC EcoComfort must be mounted on the wall with the wall bracket provided. Fasten the bracket with suitable screws (not included) for the type of wall material. Make sure the bracket is screwed securely in a horizontal position. Then hang the box on the bracket and secure with a screw in the mounting ear underneath the box. For offset dimensions, see sections Dimensional drawing and *Technical data*.



3.3 Water quality, cold side

Approved antifreeze liquids are propylene/ethylene glycol and ethyl alcohol with max. 30% concentration by volume. The suitability of other antifreeze liquids can be considered after checking the materials used in constituent components. Note that the unit capacity is specified for ethyl alcohol which is 30% by volume.

3.4 Water quality, hot side

The radiator system's water flow passes through the heat exchanger in CTC EcoComfort. This is why the radiator system must be flushed thoroughly before installation. If dirt is to be expected, the installation of a dirt filter before EcoComfort is recommended.

3.5 Delivery inspection

Check that the product has not been damaged in transit. Report any transportation damage to the carrier. Check that the delivery is complete.

3.6 General comment on pipe installation

The installation must be carried out in accordance with current standards and regulations.

3.7 Connection to the heating system


The outgoing water (cooled water) from EcoComfort is connected to a fan coil unit or to the heating/cooling system via a diverting valve (Y60). See chapters *Schematic diagrams* and *Connecting the diverting valve (Y60)*. The cooling flow back to EcoComfort should be connected to the heating/cooling system's return line.

In cases where one or more fan coil units are connected, it is the return water from the fan coil system that is connected to the cooling unit's incoming pipe. Note that the cooling unit does not contain a circulation pump for the hot side; this must be dimensioned and connected separately.

3.8 Connecting the diverting valve (Y60)

Connect the diverting valve according to the instruction below. The diverting valve must be part of the installation showed in Alt.1 (common underfloor heating/cooling).

Diverting valve ESBE VRG 230/Ara 635




The mixing valve motor is mounted on the valve with the knob in the centre position.

The valve can be mounted inversely, right to left, left to right.

The direction of the motor can be changed using the loop under the actuator cap.

The loop is always connected towards the heat pump.




Diverting valve LK EMV 110-K

When the motor transfers power to the black wire, port A opens and port B closes.

Flow AB to A = hot water production and **Black** is powered.

NB: The valve must be “turned round” in order to change direction. The valve must always be fitted so that the flow can move freely.



3.9 Non-return valve, cooling circuit

A non-return valve is pre-installed in the unit at the factory to prevent a short-circuiting flow when the cooling pump is stationary.

3.10 Non-return valves, main circuit's brine system

The delivery includes a non-return/throttle valve (int. 1" thread) which must be mounted in the brine system's main flow between the heat pump and cooling unit; see schematic diagram for connection. Make sure the valve is installed with the correct flow direction; see the marking on the valve. The valve prevents a short-circuiting flow when the heat pump's brine pump is stationary.



3.11 Bleeding the cooling unit

A manual bleeding valve is mounted in the cooling unit on the cold side's highest point. The valve is not designed to bleed the entire cold side system, but only to bleed the parts of the exchanger system. Ensure that liquid drawn out is collected and disposed of. Re-bleeding/checks may be needed after a few days.

3.12 Connection to the brine system

The cooling unit is connected to the incoming and outgoing collector pipes for the bore hole. The cooling unit's incoming fluid connection is connected to the brine pipe coming from the bore hole while its outgoing fluid connection is connected to the brine pipe that goes to the bore hole. Do not forget to install the non-return valve in the main brine circuit.

3.13 Insulating the pipes


The brine pipes must be insulated against condensation right up to and tightly against the cooling unit's box. Use insulation that is intended for protection against condensation.

The pipes of the heating system must be insulated with thermal insulation.

3.14 Pressure drop curves for CTC EcoComfort


Pressure drop, radiator side (hot side)

Including pipe and mixing valve.




Pressure increase, brine side (cold side)

Including pipe and non-return valve.



Pump capacity Grundfos Alpha 2 15-60



4. Electrical connection


Installation, switching and any servicing of the product's electrical attachments must be performed by a qualified electrician. All wiring must be done according to current regulations.

All cooling control takes place from the control system in the CTC controlling product.

The radiator pump, mixing valve motor and sensors of the CTC EcoComfort as well as the diverting valve (Y60) (in case of common underfloor heating/cooling), must be connected to the corresponding block in the controlling product. See also chapter *Electrical Installation* in the controlling product's manual.

Electrical components

The figures below show designation and placement of the electrical components in CTC EcoComfort (left) and the *common heating/cooling* circuit (right).



4.1 Alt. 1. Connection to CTC controlling product, common underfloor heating/cooling

Component	Designation, component	Block in controlling product	Cable	Note
Radiator pump 1, used for both heating and cooling	G1	A31 A33 PE	L1 Neutral Earth	230V 1N~ (Not mounted in CTC EcoComfort)
Radiator pump 2, cooling pump in CTC EcoComfort	G2, G3*	A36 A34 PE	L1 Neutral Earth	230V 1N~
Mixing valve in CTC EcoComfort	Y2, Y3*	A15 A16 A17	Open signal (white 3) Close signal (brown 1) Neutral (blue 2)	230V 1N~ Fully open = 10 (cooling) Fully closed = 0 (no cooling)
Diverting valve	Y60	A36 A25 A26	Relay output Phase Neutral	230V 1N~ Fully open= cooling Fully closed= no cooling
Primary flow sensor 1	B1	G13 G14	Pole-independent Pole-independent	Extra low voltage protection
Primary flow sensor 2	B2	G15 G16	Pole-independent Pole-independent	Extra low voltage protection
Room sensor	B11	G17 G18 G19	RG-1 (block in the room sensor) RG-2 (block in the room sensor) RG-4 (block in the room sensor)	Extra low voltage protection

* valid for EcoLogic Pro/L and EcoZenith i550/i555 Pro

4.2 Alt. 2. Connection to CTC controlling product, underfloor/ radiator heating and separate cooling coil units

Component	Designation, component	Block in controlling product	Cable	Note
Radiator pump 1, for the heating system	G1	A31 A33 PE	L1 Neutral Earth	230V 1N~ (Not mounted in CTC EcoComfort)
Radiator pump 2, cooling pump in CTC EcoComfort	G2, G3*	A36 A34 PE	L1 Neutral Earth	230V 1N~
Mixing valve in CTC EcoComfort	Y2, Y3*	A15 A16 A17	Open signal (white 3) Close signal (brown 1) Neutral (blue 2)	230V 1N~ Fully open = 10 (cooling) Fully closed = 0 (no cooling)
Primary flow sensor 1, for the heating circuit	B1	G13 G14	Pole-independent Pole-independent	Extra low voltage protection
Primary flow sensor 2, for the cooling circuit	B2	G15 G16	Pole-independent Pole-independent	Extra low voltage protection
Room sensor 1, for the heating circuit	B11	G17 G18 G19	RG-1 (block in the room sensor) RG-2 (block in the room sensor) RG-4 (block in the room sensor)	Extra low voltage protection
Room sensor 2, for the cooling circuit	B12	G20 G21 G22	RG-1 (block in the room sensor) RG-2 (block in the room sensor) RG-4 (block in the room sensor)	Extra low voltage protection

* valid for EcoLogic Pro/L and EcoZenith i550/i555 Pro

5. First start

5.1 After installation

Check that:

1. All sensors have been mounted in the designated spaces.
2. All connections are properly installed, the systems are filled with liquid and have been pressure tested and checked for tightness.
3. The system is pressurised and bled. Make extra sure that the heat exchanger in CTC EcoComfort is bled; use the air valve in the unit. Additional bleeding may be needed after start-up.

5.2 Start-up

Switch on the main switch for the CTC controlling product.

5.3 Selecting cooling function

The cooling function can now be selected in the controlling product's menu system. Go to the "Advanced/Define/Cooling" menu and select "Yes".

5.4 Selecting system type/Menu settings

For menu settings, see the Installation & Maintenance Manual for the controlling product.

5.5 Bleeding and function test



Additional bleeding can now be performed by manually activating the pump and mixing valve in the controlling product (the mixing valve in CTC EcoComfort also has a "manual mode"). Push in and twist as shown in the picture to release the mixing valve knob.

After activating the cooling function in the controlling product, check the following by going to the "Advanced/Service/Function test" menu on the controlling product:

- The pump in CTC EcoComfort receives power when activated.
- The mixing valve closes (moves towards zero) when the "reduce" signal is activated.
- The mixing valve opens (moves towards 10) when the "increase signal" is activated.



! For menu settings, see the Installation & Maintenance Manual for the controlling product.



Disengaging the mixing valve for manual mode.

6. Operation and maintenance

6.1 After installation

Once the system has been installed, the user and installer must together check that the system is in perfect working order. Let the installer show you where the power switches, controls, valves, safety valves, etc. are so that you know how the system works and how it should be maintained.

The system may need to be re-bled after a few days of operation. Also check for any leakage after a few days of operation; re-tighten if necessary.

6.2 Periodic maintenance

CTC EcoComfort does not normally require any special maintenance, although it should be checked for leakage and residual air:

- Immediately after installation and pressurisation of the systems.
- After a week of operation.
- After about a month of operation, then each year (leakage).

6.3 Breaks in operation


If the unit is to be turned off for a period of time, ensure the following:

- The taps, valves, etc. are closed/set to a position that means the system cannot be damaged during this period.
- The whole system is drained of water (the cold side does not need to be drained since it is protected against frost). Make sure that electrical power is cut off to pumps etc.
- Safety valves and other functions are checked when the system is restarted.
- When draining, make sure all water is drained from the heat exchanger; remove one of the lower connections.

6.4 Function description

Passive cooling


Passive cooling means that the free cooling available is made use of. In this case, the bore hole's cool temperature cools the radiator water. The compressor in the heat pump is not used; only pump energy is required to circulate the water.



6.5 Function options


Combination underfloor heating/cooling

To take advantage of passive cooling, you need to have an underfloor heating system to which cooling can be connected. If the underfloor heating system can be used to cool the property, it will be used for heating in the winter and cooling in the summer.



Separate heating/radiator system and cooling system (fan coil unit)

EcoHeat can handle a radiator system for heating and a separate system for cooling simultaneously. This may be appropriate if you want to cool a certain part of a property with e.g. a fan coil unit while another part requires heating.



Standard radiators (elements)

A standard radiator system with elements is not suitable for cooling. In such cases, the system must be supplemented with fan coil units (air/water heat exchanger with built-in fan, only for cooling).

Cooling capacity

Passive cooling is a cost-effective way to take advantage of the cooler temperature in the bedrock in the summer. How much you can cool a property is dependent on several factors, such as the bedrock temperature currently available, house size, capacity of the underfloor heating/fan coil units, lay-out (fan coils), etc.

Yet a drop of a few degrees in a warm house often feels much more comfortable. Often the capacity (cooling) is reduced during the latter part of the summer as the bore hole heats up.

Desired room temperature

The desired room temperature is set on the controlling product's display. The automated control system "mixes" to the right temperature in relation to the need for cooling (room sensor difference). The greater the difference, the colder the water that goes to the system. Depending on the system, excessively cold temperatures (which can result in damp damage) are not permitted.

NOTE! The recommended room temperature setting when cooling is a few degrees higher than the temperature set in heating mode. Since the room temperature tends to rise when the outdoor temperature is increasing, the cooling function takes effect.

Also note that the cooling capacity depends on factors such as the bore hole temperature, bore hole length, flows and the underfloor heating/fan coil unit capacity, and will vary during the warm season.

Automatic heating-cooling function

Once the settings have been made, operation is fully automatic. The control system automatically ensures that the property is heated when there is a need for heating and cooled when there is a need for cooling without the systems "fighting" each other.

Automatic running of pump and mixing valve

The pump and mixing valve built into CTC EcoComfort are run regularly to prevent them seizing up.

7. Troubleshooting and remedial action

Symptom													Action/comment		
X = probable cause O = possible cause															
	Normal, nothing wrong	Inadequate insulation/no condensate drain	Mixing valve incorrectly connected in the controlling product	Mixing valve set to manual mode	Sluggish underfloor heating system	Restricted cooling due to non-cond-proof system	Setting error	Cooling effect from bedrock insufficient	Room sensor misplaced	Inadequate bleeding (cold side)	Inadequate bleeding (hot side)	Underfloor heating group stops (closed)	Mixing valve in CTC EcoComfort not working	Pump in CTC EcoComfort stationary	
No cooling (after installation)			X	X			X		X	X	X	X	O	X	The entire installation should be checked
No cooling (but has worked for a long time prev.)				O		O	O		O			O	X	X	Has it been extremely hot compared to before? Check function of components.
Insufficient cooling				O	O	X	X	X	X	O	O	O	O		Installation of fan coil unit?
Too cold indoors			X	O			X		X				X		Risk of condensation? Check installation immediately!
Uneven cooling				O	O		O	O	X	X	X	O			
Condensation forms on pipe		X													Insulate! Risk of damage to the property.
Condensation from the fan coil		X													Insulate! Risk of damage to the property.
Floors too cold	X			O			X								Check installation immediately, risk of condensation? Could be one person's feeling. Install fan coil unit?
Gurgling noise										X	X				
No cooling when heat pump produces hot water	X														When brine pump in the controlling product is on, it obstructs brine flow through CTC EcoComfort, which can lower cooling capacity temporarily.

Troubleshooting CTC EcoComfort's components

The circulation pump and mixing valve motor in CTC EcoComfort can be activated separately from the menu system in the controlling product. See the the controlling product's Installation & Maintenance Manual for service functions.

7.1 Capacity data

2°C brine				Resultat		5°C brine				Resultat		10°C brine				Resultat	
②	③	④		⑤													
Flöde brine l/s	Varm T °C	Flöde radiator l/s		Kapacitet kW	Varm temp sänks K	Flöde brine l/s	Varm T °C	Flöde radiator l/s		Kapacitet kW	Varm temp sänks K	Flöde brine l/s	Varm T °C	Flöde radiator l/s		Kapacitet kW	Varm temp sänks K
0,1	15	0,1		2,8	6,7	0,1	15	0,1		2,1	5	0,1	15	0,1		1,1	2,6
		0,4		3,7	2,2			0,4		2,9	1,7			0,4		1,3	0,8
		0,7		4,5	1,5			0,7		3,5	1,2			0,7		1,6	0,5
		1		4,8	1,1			1,0		3,8	1,3			1		1,7	0,4
20	0,1			3,9	9,3	20	0,1			3,3	7,9	20	0,1			2,3	5,5
		0,4		5,1	3			0,4		4,5	2,7			0,4		2,8	1,7
		0,7		6,3	2,2			0,7		5,4	1,8			0,7		3,3	1,1
		1		6,7	1,6			1		5,8	1,4			1		3,6	0,9
25	0,1			5	12	25	0,1			4,4	10,5	25	0,1			3,3	7,9
		0,4		6,5	3,9			0,4		6,1	3,6			0,4		4,1	2,4
		0,7		8	2,7			0,7		7,4	2,5			0,7		4,8	1,6
		1		8,6	2,1			1		7,8	1,9			1		5,3	1,3
30	0,1			6,2	15	30	0,1			5,5	13,1	30	0,1			4,4	11
		0,4		8,1	4,8			0,4		7,6	4,5			0,4		5,4	3,2
		0,7		10	3,4			0,7		9,1	3,1			0,7		6,4	2,2
		1		10,7	2,6			1		9,7	2,3			1		7	1,7
0,4	15	0,1		3,7	8,8	0,4	15	0,1		2,9	6,9	0,4	15	0,1		1,3	3,1
		0,4		7,9	4,7			0,4		6	3,6			0,4		3,1	1,9
		0,7		8,8	3			0,7		6,7	2,3			0,7		3,5	1,2
		1		9,3	2,2			1		7,2	1,7			1		3,7	0,9
20	0,1			5,1	12	20	0,1			4,5	10,8	20	0,1			2,8	6,7
		0,4		11	6,6			0,4		9,2	5,5			0,4		6,5	3,9
		0,7		12,2	4,2			0,7		10,3	3,5			0,7		7,3	2,5
		1		13	3,1			1		11	2,6			1		7,8	1,9
25	0,1			6,5	16	25	0,1			6,1	14,6	25	0,1			4,1	9,8
		0,4		14	8,4			0,4		12,5	7,5			0,4		9,4	5,6
		0,7		15,6	5,3			0,7		14	4,8			0,7		10,7	3,7
		1		16,5	3,9			1		14,9	3,6			1		11,4	2,7
30	0,1			8,1	19	30	0,1			7,6	18,2	30	0,1			5,4	13
		0,4		17,5	11			0,4		15,4	9,2			0,4		12,4	7,4
		0,7		19,4	6,6			0,7		17,3	5,9			0,7		14,1	4,8
		1		20,6	4,9			1		18,4	4,4			1		15	3,6
0,7	15	0,1		4,5	11	0,7	15	0,1		3,5	8,4	0,7	15	0,1		1,6	3,8
		0,4		8,8	5,3			0,4		6,7	4			0,4		3,5	2,1
		0,7		10,5	3,6			0,7		8,1	2,8			0,7		4,2	1,4
		1		11	2,6			1		8,6	2,1			1		4,5	1,1
20	0,1			6,3	15	20	0,1			5,4	12,9	20	0,1			3,3	7,9
		0,4		12,2	7,3			0,4		10,3	6,2			0,4		7,3	4,4
		0,7		14,6	5			0,7		12,5	4,3			0,7		8,9	3
		1		15,4	3,7			1		13,1	3,1			1		9,4	2,2
25	0,1			8	19	25	0,1			7,4	17,7	25	0,1			4,8	12
		0,4		15,6	9,3			0,4		14	8,4			0,4		10,7	6,4
		0,7		18,6	6,3			0,7		16,9	5,8			0,7		13	4,4
		1		19,6	4,7			1		17,8	4,3			1		13,8	3,3
30	0,1			10	24	30	0,1			9,1	21,7	30	0,1			6,4	15
		0,4		19,4	12			0,4		17,3	10,3			0,4		14,1	8,4
		0,7		23,3	8			0,7		20,9	7,1			0,7		17,2	5,9
		1		24,5	5,9			1		22	5,3			1		18,2	4,3
1	15	0,1		4,8	12	1	15	0,1		3,8	9,1	1	15	0,1		1,7	4,1
		0,4		9,3	5,6			0,4		7,2	4,3			0,4		3,7	2,2
		0,7		11	3,8			0,7		8,6	2,9			0,7		4,5	1,5
		1		12,1	2,9			1		9,4	2,2			1		4,9	1,2
20	0,1			6,7	16	20	0,1			5,8	13,9	20	0,1			3,6	8,6
		0,4		13	7,8			0,4		11	6,6			0,4		7,8	4,7
		0,7		15,4	5,3			0,7		13,1	4,5			0,7		9,4	3,2
		1		16,9	4			1		14,5	3,5			1		10,5	2,5
25	0,1			8,6	21	25	0,1			7,8	18,6	25	0,1			5,3	13
		0,4		16,5	9,9			0,4		14,9	8,9			0,4		11,4	6,8
		0,7		19,6	6,7			0,7		17,8	6,1			0,7		13,8	4,7
		1		21,5	5,1			1		19,6	4,7			1		15,3	3,7
30	0,1			10,7	26	30	0,1			9,7	23,2	30	0,1			7	17
		0,4		20,6	12			0,4		18,4	11			0,4		15	9
		0,7		24,5	8,4			0,7		22	7,5			0,7		18,2	6,2
		1		26,9	6,4			1		24,3	5,8			1		20,1	4,8

1. Select brine temperature (closest value)
2. Select brine value (l/s)
3. Select radiator system temperature (hot T) coming into the heat exchanger.
4. Select radiator system flow (l/s)
5. Read off the capacity/cooling effect in kW, and how much the temperature of the radiator water is lowered.

The capacity values in the tables are for 100% flow through the heat exchanger, i.e. the mixing valve in CTC EcoComfort is fully open.

! The temperature of the cold water permitted to go out in the system is limited by the controlling product's control system, depending on system type and room temperature. If the cold temperature to the heating system is limited, the cooling effect is also reduced due to the reduced flow through the heat exchanger.





