



Component List

B1	Primary Flow Sensor 1
B2	Primary Flow Sensor 2
B7	Return Flow Sensor
B9	Sensor external boiler
B11	Room Sensor 1
B12	Room Sensor 2
B15	Outdoor Sensor
B30	Solar Panel Sensor in
B31	Solar Panel Sensor out
B46	Sensor diff Thermostat
B47	Sensor External Heat Source (EHS)
B50	Sensor Pool
B61	Tank sensor cooling
B72	Return flow sensor cooling
G1	Circulation Pump Heatingsystem 1
G2	Circulation Pump Heatingsystem 2 alt Free-cooling
G30	Circulation Pump Solar
G32	Circulation Pump Solar with exchanger
G40	Circulation Pump WW - Circulation
G46	Circulation Pump Diff.-Thermostat
G50	Circulation Pump Pool
G61	Circulation pump active cooling

Y2	Mixing Valve2 alt Freecooling
Y31	Exchange Valve - Recharging
Y41	Mixing Valve external heat source (EHS)
Y42	Mixing Valve external add heat
Y47	Magnetic Valve (Closes at power failure)
Y50	Exchange Valve Pool
Y60	Exchange Valve Freecooling
Y61	Exchange Valve active cooling

